**Premium Caller ID
Telephone System**

x-Lab
feel • different

User Manual
XTS-350B [Black Color]

Product of
xLabGlobal.com
in Texas, USA
MADE IN CHINA

support.xLabGlobal.com
Customer Support

warranty.xLabGlobal.com
Warranty Registration

x-Lab
feel • different

Namaste!

Thank you for purchasing our newest Specially Designed Caller ID Phone System with Super Clarity Voice Listening and Talking.
This user's manual is designed to familiarize you with your new phone. Please read it carefully before operating the phone, and follow these basic safety precautions while using it to reduce the damage to the phone and avoid the risk of fire, electric shock and injury to persons.

Note: Due to continuous Product development, all features and specifications are subject to change without prior notice.

IMPORTANT SAFETY PRECAUTIONS

Thank you for purchasing our newest Caller ID phone with voice talking. This user's manual is designed to familiarize you with your new phone. Please read it carefully before operating the phone, and follow these basic safety precautions during using to reduce the damage to the phone and avoid the risk of fire, electric shock and injury to persons:

1. The phone should be placed in cool, dry, ventilated and non-toxic places, etc.
2. Keep your phone away from moisture, dust, liquids and steam; if it gets wet or dusty, wipe it immediately.
3. Use damp soft cloth for cleaning occasionally to keep it looking new; don't use liquid cleaners or aerosol cleaners. Also make sure to disconnect the telephone line before cleaning.
4. Do not expose **LCD** in the sun for long time; and if you won't use the phone for more than a month, remove the batteries because they may leak and damage the phone.
5. Never
- Touch plug contacts with sharp or metallic objects.
- Move and operate the phone during an electrical storm, there may be a remote risk of electronic shock from lightning and thunder.
- Open the phone yourself, modifying or tampering the internal components can cause malfunction and might invalidate the warranty. If your phone is not performing as it should, take it to your local service centre for repair.
6. Other Important Tips
- Caller ID function will work only after you have subscribed for the service in the local telecom company.
- lease answer the call after the phone rings twice, otherwise there are chances that Caller ID may not come in your phone.

FREQUENTLY ASKED QUESTIONS

1. NO TONE
Please check all the lines connections, and ensure all the connections are proper.

2. CAN NOT MAKE/DIAL A CALL
Please check the lock position and ensure Keys are unlocked.

3. NOISE
Please check if the line cord or wall plug is moistured.

4. ONLY GIVING ONE RING WHILE STILL CAN MAKE A CALL
Please check the line connection, check if too many phones are connected in the same line, or the wall socket or Tel Line cord is moistured.

5. CANNOT DISPLAY CALLER ID
a. Be sure that you have applied this service from a Telecom service provider
b. Check if the battery has not drained and it has power.
c. Check if an apparatus is connected between unit and Telephone line. (Example micro filters used in an ADSL line)

If the unit still does not work properly, disconnect all the telephone cords, remove the batteries, after 5 minutes, reload batteries, insert the telephone line. The unit will get a reset. Start using the unit.

Pause- When you input the telephone number; you may press this button to input a pause time.

Out- In any mode, press **OUT** key to check the outgoing numbers with time. Use **UP/DOWN** key to review the outgoing number.

Flash-The "**Flash**" button replaces the hook switch when using features such as receive a call or making a call

Redial –
1. On standby state,press "**REDIAL**" button to redial the last dialed number;

1. Connect the phone base and handset using the supplied coiled cord.
2. Plug one end of supplied line cord into the modular line jack of the phone base and other end to the available output jack provided by local telecom office. Lift up the handset or press Hands-free key to make sure a dialing tone, otherwise check the connection.
3. Definitions
- On-hook state: The phone is in idle state with hands-free speaker deactivated and handset placed well on the phone base cradle.
- Off-hook: The phone engages the telephone line by activating the hands-free speaker or lifting up the handset.

Features
- FSK/DTMF dual system
- 30 incoming call memories, call back function
- 5 outgoing last dialed number and conversation time review and redial back
- Local area code filter
- Pre-dial and edit telephone number
- Hi/Low switch

Operation Guide

Setting the Telephone

Press the **SET** button to enter the menu and then use the **UP** or **DOWN** buttons to select the following options:

*__SET 1__ Time/Date | *__SET 2__ AREA CODE | *__SET 3__ PCODE | *__SET 4__ LCD CONTRAST

*__SET 5__ P-T | *__SET 6__ FLASH TIME

Note: The system will time out if you leave more than 8 seconds between key presses.

Setting the Time/Date

you will need to set the correct time and date so they can be displayed Correctly on the display.
If you subscribe to a caller display (FSK Type) service, the time and date will be set automatically on receipt of your first incoming call.

1. In standby mode, press the **SET** button.
   The display shows '**SET 1 DATE**'.
2. Press the **SET** button to confirm.
   The '**YEAR**' icon will be blinking.
3. Press the **UP or DOWN** button to set the year.
4. Press the **SET** button to confirm.
   The '**MONTH**' icon will be blinking.
5. Press the **UP** or **DOWN** button to set the month.
6. Press the **SET** button to confirm.
   The ' **DATE** ' icon will be blinking.
7. Press the **UP** or **DOWN** button to set the date.
8. Press the **SET** button to confirm.
   The '**HOUR**' icon will be blinking.
9. Press the **UP** or **DOWN** button to set the hour.
10. Press the **SET** button to confirm.
    The ' **MINUTE** ' icon will be blinking.
11. Press the **UP** or **DOWN** button to set the minute.
12. Press the **SET** button to confirm the setting.
    The display shows '**SET 2 CODE** ', you can continue With programming, or press the DEL button to Return to standby mode.

TO Redial the last Dialed Number

1. Lift the telephone handset.
2. Press '**REDIAL**' once, the last number will be redialed.
3. When you are dialing and if the line is busy, you can just press '**FLASH**' button once, then you need to press '**REDIAL**' button to redial the number.

TO Redial the last Dialed Number

1. Lift the telephone handset.
2. Press '**REDIAL**' once, the last number will be redialed.
3. When you are dialing and if the line is busy, you can just press '**FLASH**' button once, then you need to press '**REDIAL**' button to redial the number.

Answering Calls

1. When the unit rings, lift handset to answer.
2. When finished talking, hang up the handset again.

Using the Caller list

Review and Call Back the Caller List

1. Press **UP** or **down** to backward or forward review the number, date and time of the incoming call.
2. To search from the latest call ,press up repeatedly
3. To search from the oldest call, press down repeatedly
4. To return to the standby mode, please wait 5 seconds

1	**LCD**	:	LCD Display Screen
2	**SET**	:	Set, access the setting menu
3	**UP**	:	Review Incoming Calls / Navigation Keys During Settings
4	**DOWN**	:	Review Incoming Calls/ Navigation Keys During Settings
5	**OUT**	:	Review Outgoing calls
6	**DEL**	:	Deletes Digits & numbers
7	**RD/PAUSE**	:	Pause the last dialled number
8	**FLASH/SET**	:	Flash, Pass to another extention
9	**HOLD**	:	Redial the last dialed number

Setting the Area code

1. In standby mode,press the **SET** button.
   the display shows ' **SET 1 DATE** '.
2. Press the **UP** or **DOWN** button until the display
   Shows ' **SET 2 CODE**'.
3. Press the **SET** to confirm.
   The display shows ' **CODE xxxxx**.'
4. Press the **UP** or **DOWN** button to input your Area code.
5. Press the **SET** button to confirm the setting.
   The display shows '**SET 3 PCODE**' , you can continue
   with programming, or press the **DEL** button to return to
   Standby mode.

Setting the Pcode

Set this to your Pcode, When you receive a call, your caller ID
Will log the number which does not include any Prefix number. When you call
Back from the caller ID log, the prefix number will be auto added.

1. In standby mode, press the **SET** button.
   The display shows '**SET 1 DATE** '.
2. Press the **UP** or **DOWN** button until the display
   Shows '**SET 3 PCODE**'.
3. Press the **SET** to confirm.
   The display shows '**PCODE xxxxxx**'
4. Press the **UP** or **DOWN** button to input your Pcode.
5. Press the **SET** button to confirm the setting.
   The display shows '**SET 4 LCD**' , you can continue
   With programming, or press the **DEL** button to return to
   Standby mode.

Setting the LCD Contrast

1. In standby mode, press the **SET** button.
   The display shows ' **SET 1 DATE** '.
2. Press the **UP** or **DOWN** button until the display
   Shows '**SET 4 LCD**'.
3. Press **SET** to confirm.
4. Press the **UP** or **DOWN** button to set **LCD** contrast.
5. Press **SET** button to confirm the setting. The display shows ' **SET   P-T** ',
   you can continue with programming, or Press **DEL** button to return
   to standby mode.

Setting the P-T

1. In standby mode, press the **SET** button.
   the display shows '**SET 1 DATE** '.
2. Press the **UP** or **DOWN** button until the display
   Shows '**SET 5 P-T**'.
3. Press **SET** to confirm.
4. Press the **UP** or **DOWN** button to select **TONE** or **PULSE**.
5. Press **SET** button to confirm the setting. The display shows ' **SET   6
   FLASH** ', you can continue with programming, or Press **DEL** button
   to return to standby mode.

Making Calls

1. Lift the telephone handset
2. Dial a phone number ,then dial a number which will be displayed on
   Caller ID, eg.123456789
3. After a few seconds ,the display will begin to show the time of the call
   : "01-22" ,it means the time of the call is :1 minute and 22 seconds
4. To hang up, place the handset on the cradle.